


Multi Hz - 16 Channel Transmitter


Ref 2007350 (white) Ref 2007351 (silver)

Read instructions carefully before use.


06-17-2009




- c Product Icon d Low Battery Icon
- e Set Icon (labeling channels)
- f Channel Name g Validation Button
- h (Channel) Scroll Buttons: ◆Down Up▶
- i Up/Stop/Down j Programming Button



Normal use of the transmitter




Use the scroll buttons to select the desired channel



Stop / Intermediate Position(If Programmed) □ Down


Programming channel names and selecting product icons





button until set appears


character




Use the scroll buttons to choose the appropriate icon or blank as desired



validation button



1) The channel name can be 7 letters 2)The name can include one number




- 1) Pressing the Up

 Stop

 or Down

 button will take you out of channel name / icon selection mode.
- 2) For further motor programming functions please see the Hz02 Quick Reference Guide




that location

character locations

Technical characteristics

character location



to return to normal

mode

